


MX-B350W MX-B450W MX-B350P MX-B450P

PRODUCT CONFIGURATION

MX-B350W MX-B450W MFP

Base models include copy, print, scan, fax, 5 Line LCD operation panel, wireless and wired connectivity, 50-sheet RSPF, PCL® 6 and Adobe® PostScript® 3TM network scanning, 1 x 500-sheet paper drawer, 50-sheet bypass tray. Includes black toner (starter size; 1K each) and developer (full-size 100K yield) included.










1 1

Multifunctional Digital Document Systems - Single Drawer (included)

Desktop Printer - Single Drawer (included)

MX-B350P MX-B450P Printer

Base models include 5 Line LCD operation panel, wireless and wired connectivity, PCL® 6 and Adobe® PostScript® 3™ printing systems, auto duplexing, 1 x 500-sheet paper drawer, 50-sheet bypass tray. Includes black toner (starter size; 1K each) and developer (full-size 100K yield) included.





MX-B350W MX-B450W | MX-B350P MX-B450P

SPACE REQUIREMENTS AND PLANNING

MX-B350W/B450W

(standard drawer, table top) 550-sheet maximum

MX-B350W/B450W + MX-CS14

(1 additional drawer, table top) 1,150-sheet maximum

MX-B350W/B450W + MX-DS22N

(standard drawer, low floor standing) 550-sheet maximum

MX-B350W/B450W + MX-CS14 + MX-DS22N

(standard drawer, floor standing) 550-sheet maximum

MX-B350P/B450P

(standard drawer, table top) 550-sheet maximum

MX-B350P/B450P + MX-CS14


(1 additional drawer, table top) 1,150-sheet maximum

MX-B350P/B450P + MX-DS22N


(standard drawer, low floor standing) 550-sheet maximum


MX-B350P/B450P + MX-CS14 + MX-DS22N

(standard drawer, floor standing) 550-sheet maximum












17%"








Main Unit



Overhead View with Stand



Design and specifications are subject to change without notice. All product dimensions listed are approximate.

Plan ahead to ensure your installation is a great success! Check the latest information on these products and have the following items available prior to installation.

- Firmware: Check the Sharp-PC Service site to make sure the machine and accessories have the latest firmware prior to installation at the customer site.
- Power Source: Verify the power source at the customer site. Requires 110-127 V AC @ 60 HZ with a 15 A
 receptacle outlet and circuit breaker.
- Product Keys: Obtain application codes for any accessories that may require a product key prior to arrival
 at the customer site.
- \bullet Supplies: Verify that the customer has enough supplies on hand. Starter toner included.

MX-B45NT Toner

MX-B45NV Developer MX-B45DM Drum

MY ™ SHARP

Check to see if My Sharp™ online training is set up for the end-user.